

Support Group Application Note

Number: 005

Issue: 1

Author:



Use of *FX 3

Applicable
Hardware :

BBC B
BBC B+
BBC Master 128

Related
Application
Notes:

Copyright © Acorn Computers Limited 1992

Every effort has been made to ensure that the information in this leaflet is true and correct at the time of printing. However, the products described in this leaflet are subject to continuous development and improvements and Acorn Computers Limited reserves the right to change its specifications at any time. Acorn Computers Limited cannot accept liability for any loss or damage arising from the use of any information or particulars in this leaflet. ACORN, ECONET and ARCHIMEDES are trademarks of Acorn Computers Limited.

Support Group
Acorn Computers Limited
Acorn House
Vision Park
Histon
Cambridge CB4 4AE

USE OF *FX 3**Output characters destination**

As a result of errors and omissions in the BBC User Guide, use of the *FX 3 command is difficult, particularly when one destination, which is not the screen, is required.

The error in the User Guide is as follows:

page 422: The chart of written character destinations shows four ticks in the Printer [Bit 2] column. There should not be ticks for *FX 3,2 and 3,3.

There is an undocumented bit of this word (bit 3) which allows other bits to be overridden; this is summarised in the chart below:

Value of n in decimal	Value of n in binary				EFFECT			
	Bit 3	Bit 2	Bit 1	Bit 0	Printer	Screen	RS423	
0	0	0	0	0	/+	/	x	+ Printer controlled by VDU 1,2 3 and *FX5 and *FX6
1	0	0	0	1	/+	/	/	
2	0	0	1	0	x	x	x	
3	0	0	1	1	x	x	/	
4	0	1	0	0	x	/	x	
5	0	1	0	1	x	/	/	
6	0	1	1	0	x	x	x	
7	0	1	1	1	x	x	/	
8	1	0	0	0	/*	/	x	* Printer controlled by *FX5 and *FX6 and automatically enabled
9	1	0	0	1	/*	/	/	
10	1	0	1	0	/*	x	x	
11	1	0	1	1	/*	x	/	
12	1	1	0	0	x	/	x	
13	1	1	0	1	x	/	/	
14	1	1	1	0	x	x	x	
15	1	1	1	1	x	x		

Table 1 - the effect of *FX3.n

Note that the appropriate printer must have been selected with *FX5, and that if a serial printer is selected with FX5 and RS423 is selected from the above chart (with FX3) then the output from the RS423 port is undefined.